

## How do I adjust and fill my wood pepper mill or salt grinder?

Filling the mill is very simple- just unscrew the chrome knob on the top and pull the top straight up, reverse for reassembly. To adjust the grind after filling, simply tighten the chrome adjuster knob for finer grind. For coarser grind, simply loosen the knob a little and push down. Also note, for best grinding performance, always turn top in clockwise direction while grinding.